

SQUIER® 51 0325100

SWITCH&CONTROL FUNCTION

3 WAY SWITCH POSITION						
PUSH	PULL	PUSH	PULL	PUSH	PULL	← PUSH PULL SWITCH
						← 3WAY ROTARY SWITCH POSITION
MV	MV	MV	MV	MV	MV	← VOLUME CONTROL
						← NECK PICKUP
						← BRIDGE PICKUP
	← PICKUP IS ON					← PICKUP IS OFF

